



YAMAHA BOLT GRAND PRIX SLIP-ON PART # 18-1002 INSTALLATION INSTRUCTIONS

Congratulations, you are no longer on the beaten path. Sometimes the high road takes you to new places. You won't regret it, we never have. Our parts are expertly crafted and designed for maximum performance, deep throaty sound, perfect fit and innovative styling. Firebrand exhaust systems are the first choice for people whose passion is riding. Please follow the installation instructions below and if you have any questions, please call our technical support line Toll Free at 844-FIREONE (347-3663).

Attention installer (if other than owner), please forward this instruction sheet to the owner of this product. These instructions contain valuable information to the end user.

1. Unplug the O2 sensor from the wiring harness.
2. Remove the bolts that attach the stock muffler to the mount bracket.
3. Loosen the clamp at the front of the muffler and remove the muffler assembly.
4. Carefully remove the stock gasket from the front of the muffler, along with the stock heat shield and O2 sensor.
5. Working on a non-abrasive surface such as a blanket or carpet remove Firebrand muffler and heat shield from protective packaging.
6. Apply masking tape to the front edge of the muffler casing where the heat shield will butt up, this will help prevent scratching during installation.
7. Using the provided washers and button head capscrews install the stock heat shield to the supplied heatshield.
8. Lay heat shield onto tail pipe and loosely install hose clamps by feeding tail end of clamp into heat shield clips. The heat shield only fits correctly when the internal hose clamp clips are rearward and closest to the muffler casing. NOTE: Screw heads should be accessible from underside of bike when system is installed on motorcycle.
9. Apply a small amount of anti-seize compound to the threads of the O2 sensor and install into the tail pipe. NOTE: Be careful not to get anti-seize on sensor tip, it may affect sensor function.
10. Install stock gasket and clamp into the front of the tail pipe and slip onto head pipe.
11. Using the supplied flange bolts and sleeves attach the muffler to the mount bracket.
12. Visually inspect alignment and tighten muffler to bracket followed by the front clamp.
13. Align heat shield and be sure it is not rubbing on muffler casing and tighten hose clamps.
14. Remove any tape from muffler casing and plug O2 sensor back into wiring harness.
15. Check for adequate clearance of all exhaust system components and motorcycle accessories prone to heat damage.
16. We highly recommend the use of thread locking compound on all hardware during installation. Be sure to tighten all hardware before starting motorcycle.
17. Now get out there and RIDE!

18-1002 BLACK

After installation and before starting your motorcycle, completely clean mufflers with warm soapy water and a clean soft cloth. Dry with a clean towel. NOTE: any residue, oil, or fingerprints will stain the black ceramic coating. Do NOT use anything abrasive to clean the pipes as it may remove the finish.

DISCLAIMER

Firebrand exhaust systems are warranted against defects in material and workmanship for a period of 1 year from the date of purchase from an authorized dealer. This warranty does not cover discoloration or rust of chrome finishes. This warranty is limited to the repair or replacement of a product proven to be defective from normal use. Firebrand exhaust systems are designed to fit and operate on OEM motor and chassis. This warranty does not cover any product subject to abuse, misuse, improper installation or modification. Every effort is made for Firebrand Exhaust Systems to provide improved cornering clearance. However, due to design and space limitations on some motorcycle models, ground and cornering clearance may not be improved and in some cases may be reduced. Be sure to follow proper installation instructions. Aftermarket products that remove OEM pollution control components are not permitted for street use in California. Please check with your local Municipality or visit the CARB website at www.arb.ca.gov.

TOOLS REQUIRED

- 10, 12, 14 & 22mm WRENCHES
- 4, 6, & 8mm ALLEN WRENCHES
- 13 & 14mm SOCKETS & RATCHET
- 5/16" NUTDRIVER OR SCREWDRIVER

firebrandTM
ANYTHING BUT NEUTRAL



REV. A_11/15

