



DYNA SWITCHBACK/ LOWRIDER SLIP-ON PART # 13-1005 INSTALLATION INSTRUCTIONS

Congratulations, your husband has purchased the finest exhaust system for his, or your, motorcycle. If he's like most guys we are assuming he hasn't read these instructions, which is where you come in. Keep a careful eye on him and when he says he's stuck hand him this Instruction sheet, we included it for a reason. Now for the good news, you picked a great product to enhance the riding experience. Expertly crafted and designed for maximum performance, deep throaty sound, perfect fit and innovative styling. Firebrand exhaust systems are the first choice for people whose passion is riding. Please follow the installation instructions below and if you have any questions, please call our technical support line Toll Free at 844-FIREONE (347-3663). Attention installer (if other than owner), please forward this instruction sheet to the owner of this product. These instructions contain valuable information to the end user.

1. *If equipped, remove the saddlebags from your motorcycle.*
2. *Loosen the Torca band clamp on the front of the muffler.*
3. *Remove the 5/16" nut from the rear mount pin and the 5/16" bolt from the front of the mount bracket.*
4. *Now slide the muffler off of the head pipe. NOTE: It may be necessary to use a penetrating lubricant to loosen the muffler from the head pipe.*
5. *Remove the band clamp from the front of the OEM muffler and install it in the same manner onto the Loose Cannon muffler.*
6. *Install muffler by sliding it onto the head pipe and bolting it to the mount brackets using the OEM bolts. We recommend the use of a thread locking compound on all hardware.*
7. *Tighten the band clamp. Torque spec. is 40-45 Ft./Lbs. NOTE: Visually check alignment while you tighten the hardware.*
8. *Tighten all hardware before starting your motorcycle.*
9. *Replace the saddlebags.*
10. *Now go and ride, NO EXCUSES!*

IMPORTANT, PLEASE READ!

After installation and before starting your motorcycle, clean pipes and mufflers with a cleaning solvent and a clean soft cloth that will not leave a residue. NOTE: Any residue, oil, or fingerprints will stain the chrome when the metal heats up.

DISCLAIMER

Firebrand exhaust systems are warranted against defects in material and workmanship for a period of 1 year from the date of purchase from an authorized dealer. This warranty does not cover discoloration or rust of chrome finishes. This warranty is limited to the repair or replacement of a product proven to be defective from normal use. Firebrand exhaust systems are designed to fit and operate on OEM motor and chassis. This warranty does not cover any product subject to abuse, misuse, improper installation or modification. Every effort is made for Firebrand Exhaust Systems to provide improved cornering clearance. However, due to design and space limitations on some motorcycle models, ground and cornering clearance may not be improved and in some cases may be reduced. Be sure to follow proper installation instructions. Aftermarket products that remove OEM pollution control components are not permitted for street use in California. Please check with your local Municipality or visit the CARB website at www.arb.ca.gov.

TOOLS REQUIRED

- RATCHET
- 1/2" SOCKET
- 9/16" DEEP SOCKET
- 1/2" COMBINATION WRENCH

firebrandTM
ANYTHING BUT NEUTRAL



REV. A_4/15